



SHELF TOOL CART

PN: R1152



USER MANUAL



RHINOMOTIVE LTD - UK
71-75 Shelton Street, London, United Kingdom
www.rhinomotive.com

Scan QR Code

IMPORTANT WARNING!

ADULT ASSEMBLY REQUIRED

Assembly kit contains small parts that can present choking hazards for children.

Assembly kit contains small parts with sharp points.

Assembly kit contains small parts with sharp edges.

Components are packed in plastic bags that could present a suffocation hazard. Dispose of plastic bags as soon as unpacked.

1. APPLICATION/USE

Used in body shops, detailing centres, PDI, etc. to store and carry RHINOMOTIVE products, tools and cleaning equipment.

2. TECHNICAL SPECIFICATIONS

- Material: Polypropylene Plastic & Aluminium
- Size: 56cm (L) x 42cm (W) x 90cm (H)





Use model of hanging bucket for cart

External



Internal



3. PARTS LIST

NO.	DESCRIPTION	QUANTITY
1	Top Plastic Shelf	1
	Middle Plastic Shelf	1
	Bottom Plastic Shelf	1
2	Handle	2
3	Caster 3"	4
4	Aluminium Pillar	8
5	Storage Bucket	2
6	Bottle Hanger	6
7	Hook Plate	2
8	Small Hook	4
	Large Hook	4
	Open Clamp	8

4. ASSEMBLY INSTRUCTIONS

4.1. Insert the aluminium pillars into the bottom plastic shelf as shown in image (1), repeat the process for middle and top shelf.



4.2. Insert the handles into top shelf tool cart as shown in image (2).



4.3. Insert the casters into the bottom shelf as shown in image (3) and tighten them securely.

3



4.4. Attach the storage buckets from the front of shelf tool cart as shown in image (4).

4



4.5. Attach the bottle hangers to the side of top shelf as shown in image (5).

5



4.6. Attach the hook plate to the back of the shelf tool cart, fix the hooks and clamps on the hook plate as shown in image (6).



6

**PRO
SERIES** | **USE IT AND SEE
THE DIFFERENCE**



RHINOMOTIVE LTD - UK
71-75 Shelton Street, London, United Kingdom
www.rhinomotive.com

Scan QR Code